

OLD WOOD/NEW WOOD

STEP BY STEP INSTRUCTIONS

- 1) Sand wood with FESTOOL Dustless Sander using 80 grit paper to remove old finish followed by 180 grit to smooth.
- 2) Apply 1 coat with rag of OLD MASTERS WOOD CONDITIONER to surface. Do not flood the wood, but dampen the whole surface.
- 3) Stain surface with OLD MASTERS WIPING STAIN while conditioner is still damp. Apply evenly to you're liking and let dry overnite.
- 4) Apply 1 coat of OLD MASTERS SANDING SEALER with a china bristle brush.
- 5) After 2-3 hours, sand the surface with 220 - 400 grit sand paper. Remove dust with a tack cloth and/or rag dampened with paint thinner.
- 6) Apply coat of OLD MASTERS POLYURETHANE to sheen of choice. Use a china bristle brush only. Let dry overnite.
- 7) Sand surface with 220 - 400 grit sandpaper. Remove dust with a tack rag and/or rag dampened with paint thinner.
- 8) Apply final coat of OLD MASTERS POLYURETHANE and allow to dry overnite.
- 9) Allow coating to cure 1 week before putting into full service.

MATERIALS LIST:

Festool Dustless Sander Rental
Festool Abrasives
Old Masters Wood Conditioner
Old Masters Wiping Stain
Old Masters Sanding Sealer
Old Masters Polyurethane
Paint Thinner

Tack Rags
Corona China Bristle Brush
220 - 400 Grit Sandpaper
Rags
STAINS USED ON SAMPLES:
American Walnut
Puritan Pine

